



RKF 8CH TRANSMITTER



MAINS FAILURE CONNECTIONS



NOTE:

For external mains failure detection connect zone 8 to one of the two, 16V AC inputs

NOTE: External trigger from another alarm panel can be either N/O (by applying 12V DC) or N/C by removing 12V DC)

L B S 8 7 6 5 4 3 2 1 C

ARM/DISARM LED (OPEN COLLECTOR)

BUZZER OUT (OPEN COLLECTOR)

SIREN TRIGGER OUT (OPEN COLLECTOR)

INPUT 8

INPUT 7

INPUT 6

INPUT 5

INPUT 4

INPUT 3


INPUT 2

INPUT 1

COMMON +12VDC TO DETECTORS C

(13.8VDC) -VE IN -

+VE IN +



(S0022DFX Xtal)
(S0022FXX Synth)

RKF 8CH TX INSTALLATION MANUAL

PROGRAMMING OPTION REGISTERS (USE THE RKF PROGRAMMER)

1 & 2

TO PROGRAM:
 1. HOLD THE SELECTED REGISTER KEY UNTIL A "P" IS DISPLAYED (E.G. "3") **3** **P**
 2. ENTER EIGHT "0" OR "1" AS SELECTED **?** **0** OR **1**

TO VISUALIZE:
 PRESS SHORTLY THE NUMBER OF THE REGISTER YOU WANT TO CHECK. **?**
 THE DISPLAY WILL SHOW SEQUENTIALLY THE CONTENT OF THE REGISTER **0** OR **1**

OPTIONS REGISTER NO. 1

1

- | | | |
|---------------------------------|---------------------|---|
| ON= SIREN WITH REMOTE PANIC | OFF= NO SIREN | 1 |
| ON= 3 MINUTE SIREN | OFF= 3 SECOND SIREN | 2 |
| ON= SIREN BEEPS WITH ARM/DISARM | OFF= NO SIREN BEEPS | 3 |
| ON= N/A | OFF= N/A | 4 |
| ON= see table | OFF= see table | 5 |
| ON= see table | OFF= see table | 6 |
| ON= see table | OFF= see table | 7 |
| ON= see table | OFF= see table | 8 |

FACTORY DEFAULT

DO YOU WANT TO TRANSMIT TO THE BASE VIA A REPEATER ?

5	0		0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
6	0		0	0	1	1	0	0	1	1	0	0	1	0	0	1	1	0	0	1	0	0	1	1	0	1
7	0		0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	1
8	0		0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

OPTIONS REGISTER NO. 2

2

NEW

- | | | |
|-----------------------------------|---------------------------------------|---|
| ON= N/A | OFF= N/A | 1 |
| ON= N/A | OFF= N/A | 2 |
| ON= REPORT BATTERY LOW IN SENSORS | OFF= NO REPORT | 3 |
| ON= REPORT ARMING/DISARMING | OFF= NO REPORT | 4 |
| ON= REPORT SYSTEM BATTERY LOW | OFF= DO NOT REPORT SYSTEM BATTERY LOW | 5 |
| ON= SEND ZONE 8 AS MAINSFAIL | OFF= SEND ZONE 8 AS NORMAL | 6 |
| ON= SEND FTX PROTOCOL | OFF= SEND DTMF PROTOCOL | 7 |
| ON= N/A | OFF= N/A | 8 |

FACTORY DEFAULT

BIT	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
BINARY	0	1	0	1	0	1	1	1	0	0	1	0	0	0	0	0
DECIMAL	1	2	4	8	16	32	64	128	256	512	1024	2048	4096	8192	16384	32768
ADD	2 + 8		+ 32+ 64+128+		1024=		1258									

PROGRAMMING THE ZONES OPTION REGISTERS

3 TO 7

DATA IS ENTERED FROM LEFT TO RIGHT. THE FACTORY DEFAULT SETTINGS ARE GIVEN BELOW THE OPTIONS. REGISTER ZONE NUMBER WHAT TO ENTER

- | | | | | | | | | | | |
|----------------------|---|---|---|---|---|---|---|---|---|--|
| INPUT INVERT | 3 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 1 = INPUT IS NORMALLY CLOSED
0 = INPUT IS NORMALLY OPEN
← FACTORY DEFAULTS |
| INPUT DETECT TIME | 4 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 1 = 15 SECOND DETECTION TIME
0 = 0.5 SECOND DETECTION TIME
← FACTORY DEFAULTS |
| INPUT SIREN REQUEST | 5 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 1 = INPUT WILL ACTIVATE SIREN
0 = INPUT WILL NOT ACTIVATE SIREN
← FACTORY DEFAULTS |
| OPEN/CLOSE REPORT | 6 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 1 = INPUT WILL REPORT "OPEN/CLOSE"
0 = NO REPORT
← FACTORY DEFAULTS |
| ALARM/RESTORE REPORT | 7 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 1 = INPUT WILL REPORT "ALARM/RESTORE"
0 = NO REPORT
← FACTORY DEFAULTS |

PROGRAMMING THE IDENTIFICATION REGISTERS

C, D & A


- I.D. CODE OF THE TRANSMITTER OR TEL. COMMUNICATOR **C** 1 2 3 4 ENTER A 4-DIGIT NUMBER.
 5 0 0 0 0 ← FACTORY DEFAULTS
- ONLY WHEN USING RADIO OR TEL. COMMUNICATORS WITH UHF SMART CAT RECEIVER FOR REMOTE CONTROL.
- DIP-SWITCH CODING **D** 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 1 = 'ON' 0 = 'OFF' ← FACTORY DEFAULTS
- ONLY WHEN USING RADIO OR TEL. COMMUNICATORS WITH BUILT-IN UHF RECEIVER FOR REMOTE CONTROL.
- DIP-SWITCH CODING **D** 1 2 3 4 5 6 7 8 9 10 1 = 'ON' 0 = 'OFF' BITS 5 TO 10 MUST MATCH USER ← FACTORY DEFAULTS

RESET TO FACTORY DEFAULTS: HOLD KEY **9** UNTIL **3** IS DISPLAYED

PROGRAMMING THE EXTENDED OPTION REGISTERS FOR EACH ZONE

0 ?

- | | | | | | | | | | | | |
|---------------------------------|---|---|---|---|---|---|---|---|---|---|--|
| ARMED/DISARMED INPUTS | 0 | 1 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 1 = INPUT CAN BE ARMED OR DISARMED
0 = INPUT IS DISABLED
← FACTORY DEFAULTS |
| 24HRS (EMERGENCY) INPUTS | 0 | 5 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 1 = INPUT IS ALWAYS ACTIVE (24 HRS)
0 = INPUT IS DISABLED
← FACTORY DEFAULTS |
| INPUTS REQUIRING ENTRY DELAY | 0 | 6 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 1 = INPUT WITH ENTRY DELAY
0 = INPUT WITH NO ENTRY DELAY
← FACTORY DEFAULTS |
| VALUE IN SECONDS OF ENTRY DELAY | 0 | 7 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | VALUE IN SECONDS OF ENTRY DELAY (USE BINARY TABLE)
← FACTORY DEFAULTS (20 SEC) |
| AUTO TEST INTERVAL (IN HRS) | 0 | 8 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | VALUE IN HOURS OF INTERVAL BETWEEN SELF TESTS
← FACTORY DEFAULTS (48HRS) |



RKF 4CH TRANSMITTER

RKF T4

The "RKF T4" is a microprocessor based RADIO TRANSMITTER. It is designed to perform the functions associated with the monitoring of alarm conditions and subsequent transmission to a CONTROL ROOM FOR ALARM MONITORING .

Following are the features that make the "RKF T4 " the most versatile , efficient and innovative RADIO LINK in the security market:

- 1 - Four 24Hr hard wired PROGRAMMABLE INPUTS.
- 2 - Silent RADIO Remote PANIC button
- 3 -Sends the conditions of all 4 inputs when any of the INPUTS are triggered.
- 4 - All INPUTS are programmable to suit special installation requirements.
- 5 - Subscriber code and options fully programmable by the installer by making use of the M.A.M.I SPRO1 PROGRAMMER
- 6 - **EEPROM** memory for retention of options and code selections during "power-down".
- 7 - Programmable to send a "**check-in**" transmission between 1 to 250 hours.
- 8 - Programmable System Battery Low.
- 9 - Inputs can be triggered by either a positive or negative signal.

A REMOTE PANIC BUTTON is available with the addition of the Microcat Receiver..

For complete flexibility the four wired inputs may be programmed to send a transmission whenever one of the following conditions occurs:

- 1.a) - When the external circuit is opened (**Normally Closed circuit**)
- 1.b) - When the external circuit is closed (**Normally Open circuit**)
- 1.c) - Both when the external circuit is being **opened and closed**.

For example : You may require that the particular circuit calls the control room both when an alarm occurs and when it is restored, or that a particular circuit calls the control room both when a door is opened or closed.

INSTALLATION NOTES :

1 - INPUT CONNECTIONS:

There are 4 inputs available on the BOARD (**1 TO 4**). These INPUTS are factory-programmed for NORMALLY-OPEN operation, that is: You need to APPLY 12 V (from the common 12V CONNECTION P+) to trigger the alarm.

If you require any of these to be NORMALLY-CLOSED (trigger on removing 12V), it is necessary to define these circuits in the INVERT register (see "PROGRAMMING THE RKF-T4"(key.3)) Entering "1" will change that circuit from N.O to N.C

4 - RECEIVER CONNECTIONS: (for Remote Panic Button)

The external receiver (Micro-Cat - R0) must be connected before power up!
Mount the receiver no more than five metres from the unit. 12 Volts DC for the receiver is available between (-) & P(+). The third connection, (RX), to the receiver is the data connection.

5 - POWER SUPPLY: The unit works on a 12 V DC Supply.(Not less that 0.5mm cable)

8 - BATTERY CONNECTIONS: The standby battery ratings must be : 12v with a recommended capacity of 6.5 A/hr . The standby battery must be connected between **BATT(NEGATIVE)** and **BATT(POSITIVE)**. As a protection for battery polarity reversal, **crow-bar polarity protection has been implemented**. It may be therefore necessary to change the "BATTERY" fuse after connecting the battery incorrectly.

Guarantee DOES NOT cover damages caused by REVERSE/ INCORRECT connection to the battery.

PROGRAMMING THE RKF - T4

INSTALLER CODE

THE RKF-T4 IS PROGRAMMED WITH A "FACTORY DEFAULT" SET OF OPTIONS.

ALTHOUGH THE "FACTORY" OPTIONS REFLECT THE CHOICE OF THE MAJORITY OF INSTALLERS AND END-USERS, PROPER OPERATION AND COMPLIANCE WITH SPECIFIC REQUIREMENTS CAN BE ACHIEVED THROUGH REPROGRAMMING.

THE PROGRAMMABLE OPTIONS ARE DIVIDED INTO 3 SECTIONS:

- 1 - SYSTEM OPTION REGISTERS.
- 2 - SYSTEM I.D. CODES
- 3 - CIRCUIT (ZONE) OPTION REGISTERS.

PROGRAMMING:

- 1) Connect the programmer (SPRO 1) as indicated in **FIG.02**.
- 2) Hold down programming button on SPRO and apply power by connecting the 12V, release the programming button
WARNING: observe the polarity markings on the board.
- 3) Press the # (ENTER) key on the programmer. The unit will "Lock" onto the 4channel TX and will, for a brief moment, display the product number (03) of the transmitter.
- 4) Following a successful "LOCK ON ", an "F" will be displayed by the programmer.
- 5) The system is now ready to program any of the registers indicated below.
- 6) Enter # after programming each register.

SECTION 1 : SYSTEM OPTION REGISTERS

OPTIONS REGISTER NO. 1

0 1 #

NOTE: = ON
 = OFF

ON= N/A

OFF= N/A

ON= N/A

OFF= N/A

ON= N/A

OFF= N/A

ON= N/A

OFF= N/A

REPEATER BIT 1
REPEATER BIT 2
REPEATER BIT 3
REPEATER BIT 4

OFF NO REPEATER
OFF
OFF
OFF

ON REPEATER 1
OFF
OFF
OFF

OFF REPEATER 2
ON
OFF
OFF

ON REPEATER 3
ON
OFF
OFF

OFF REPEATER 4
OFF
ON
OFF

ON REPEATER 5
OFF
ON
OFF

ON REPEATER 6
ON
ON
ON

OFF REPEATER 7
OFF
ON
ON

FACTORY DEFAULT
○ 1
○ 2
○ 3
○ 4
○ 5
○ 6
○ 7
○ 8

OPTIONS REGISTER NO. 2

0 2 #

NEW!

ON= SEND FTX FORMAT

OFF= SEND DTMF FORMAT

ON= N/A

OFF= N/A

ON= N/A

OFF= N/A

ON= N/A

OFF= N/A

ON= REPORT SYSTEM BATTERY LOW

OFF= DO NOT REPORT SYSTEM BATTERY LOW

ON= N/A

OFF= N/A

ON= CHECK-IN AT TIMED INTERVALS

OFF= DO NOT CHECK-IN

ON= N/A

OFF= N/A

FACTORY DEFAULT
○ 1
○ 2
○ 3
○ 4
● 5
○ 6
● 7
○ 8

LOAD FACTORY DEFAULTS

3 7 #

NOTE: THIS OPERATION WILL ERASE ALL USER PROGRAMMING AND RESET THE RKF T4 TO FACTORY DEFAULT VALUES.

EXIT PROGRAMMING MODE

3 0 #

THIS OPERATION WILL TERMINATE THE PROGRAMMING SESSION.

SECTION 2 : SYSTEM I.D. CODES

Transmitter ID code

To change the ID code enter: **2 0 #**

To view the ID code enter: **2 0 ***

	1	2	3	4	
					ENTER A 4-DIGIT NUMBER
	0	0	0	1	← FACTORY DEFAULTS

Wnet Block Code

To change the block code enter: **2 8 #**

	1	2	
			ENTER A 2-DIGIT NUMBER
	0	0	← FACTORY DEFAULTS

To view the block code enter: **2 8 ***



ONLY WHEN USING RADIO WITH UHF RECEIVER FOR REMOTE CONTROL (10BIT ONLY).

DIP-SWITCH CODING

2 4 #

	1	2	3	4	5	6	7	8	9	10	
											1 = 'ON' 0 = 'OFF'
	0	0	0	0	0	1	1	1	1	1	← FACTORY DEFAULTS

SECTION 3 : INPUT OPTION REGISTER

(Use only the 1st four digits)

REGISTER

INPUT INVERT

0 3 #

OPEN/CLOSE REPORT

0 6 #

ALARM/RESTORE REPORT

0 7 #

INPUT CHANNEL

	1	2	3	4	
					← FACTORY DEFAULTS
	0	0	0	0	

WHAT TO ENTER

1 = INPUT IS NORMALLY CLOSED
0 = INPUT IS NORMALLY OPEN

1 = INPUT WILL REPORT "OPEN/CLOSE"
0 = NORMAL INPUT

1 = INPUT WILL REPORT "ALARM/RESTORE"
0 = NORMAL INPUT

SECTION 4 : EXTENDED OPTION REGISTER

CHECK-IN INTERVAL (IN HRS)

1 5 #

	1	2	4	8	16	32	64	128	
									VALUE IN HOURS OF INTERVAL BETWEEN SELF TESTS
	0	0	0	1	1	0	0	0	← FACTORY DEFAULTS (24HRS)

← FACTORY DEFAULTS

THIS OPTION NEEDS A VALUE (0 TO 255) TO BE ENTERED RATHER THAN INDIVIDUAL SELECTION. TO CHANGE THESE VALUES DO AS FOLLOWS:
WORK OUT WHICH OF THE INDICATED AMOUNTS CAN BE ADDED TO MAKE UP THE REQUIRED VALUE

EXAMPLE: TO CHANGE FROM 24 TO 48 HOURS.
ENTER "15#" ... THE CURRENT VALUE WILL BE DISPLAYED (LEDS 4 AND 5 = ON)
ENTER "4, 5" ... THIS WILL SWITCH OFF THESE LEDS

48 IS THE SUM OF AMOUNTS 16 + 32, WHICH CORRESPOND TO LEDS 5, and 6
ENTER "5, 6" TO TURN THESE LED'S ON.
ENTER "*" TO EXIT.

1	<input type="radio"/>	1
2	<input type="radio"/>	2
3	<input type="radio"/>	4
4	<input checked="" type="radio"/>	8
5	<input checked="" type="radio"/>	16
6	<input type="radio"/>	32
7	<input type="radio"/>	64
8	<input type="radio"/>	128

LED NO




AMOUNT REPRESENTED BY LED ON

N.B. A CHECK-IN INTERVAL OF "0" (ALL LEDS OFF) WILL AUTOMATICALLY DISABLE THE OPTION (NO CHECKING-IN TRANSMISSION).

RKF T4 PROGRAMMING

PROGRAMMING THE RKF TX 4, USE A SPRO1 (SEE CONNECTIONS BELOW)



Warning:

Please observe the polarity markings on the board.

FIG. 02

PLEASE CONNECT ALL:

- "A" on Serial Programmer to "A" on control panel
- "B" on Serial Programmer to "B" on control panel
- "+" to "+"
- "-" to "-"

RKF T4 INSTALLATION

Installing the RKF T4 is a very simple matter. All you have to do is follow the wiring diagram to connect the Inputs, Micro-Cat Receiver and Battery.




FIG. 01